



Mayco Projects Library Holiday Tree Dishes



Shapes

Mayco Bisque

[MB-1096 Christmas Tree Dishes](#)

Colors

Foundations

[FN-001 White](#)

Stroke & Coat

[SC-74 Hot Tamale](#)

Decorating Accessories

Studio Tools & Accessories

[BT-910 Synthetic Sponges](#)

Glaze Brushes

[CB-604 # 4 Soft Fan](#)

Miscellaneous Non-Mayco Supplies

3/4" Paper Punch

Plain Copy Paper

Pin

Tweezers

Paper Towels

Scissors

[Downloadable Tree Pattern](#)

Project Description:

Foundations, Stroke & Coat and paper painting make these holiday tree dishes ready for your treats.

Designer: Bob Moreni

Project Time Span: 1 hour

Skill Level: Basic

Instructions: Project instructions below. Mayco encourages you to vary colors, patterns and techniques to create your own designs.

1. Dots

1. Begin with properly fired shelf cone 04 [Bisque](#). Moisten a clean [Sponge](#) and wipe [Bisque](#) to remove any dust.
2. Using a CB-604 # 4 Soft Fan, apply 2 [Coats](#) of FN-001 to the front and back of each tree dish. Allow to dry.
3. Punch out several 3/4" paper circles from some plain copy paper.
4. Wet the paper circles with some water, place the circles onto the tree dish, and press in place. Press a paper towel over the tree dish to make sure none of the circles are raised up and to blot up any excess water.
5. Using a CB-604 # 4 Soft Fan, apply 3 [Coats](#) of SC-74 Hot Tamale to the top side of each tree dish.
6. When the SC-74 Hot Tamale has lost its shine, use a pin and tweezers to remove the circles. *Note: Make sure you remove all the circles.*
7. Allow to dry.

8. Stilt and fire to shelf cone 06.

Tree

1. Begin with properly fired shelf cone 04 [Bisque](#). Moisten a clean [Sponge](#) and wipe [Bisque](#) to remove any dust.
 2. Using a CB-604 # 4 Soft Fan, apply 2 [Coats](#) of FN-001 to the front and back of each tree dish. Allow to dry.
 3. Cut out the tree pattern.
 4. Position the cut out tree pattern in the tree dish. Brush water under the pattern then press the pattern down. Make sure all the edges of the pattern are tight against the tree dish. Press with a paper towel to aid in this.
 5. Using a CB-604 # 4 Soft Fan, apply 3 [Coats](#) of SC-74 Hot Tamale to the top side of each tree dish.
 6. When the SC-74 Hot Tamale has lost its shine, use a pin and tweezers to remove the tree pattern. *Note: Make sure you remove all of the tree pattern.*
 7. Allow to dry.
 8. Stilt and fire to shelf cone 06.
-